







Certification No.

VMA-50122-01C (Revision 7)

Expiration Date: 6/30/2027

Certification Parameters:

The nonstructural products (mechanical and/or electrical components) listed on this certificate are CERTIFIED¹ FOR SEISMIC APPLICATIONS in accordance with the following building code² releases.

IBC 2021, 2018, 2015, 2012; EC8 2004

The following model designations, options, and accessories are included in this certification. Reference report number VMA-50122-01 as issued by The VMC Group for a complete list of certified models, included accessories/options, and certified installation methods.

Cummins Power Generation, Inc.; Parallel Switchgear System Digital Master Controller: DMC2000, DMC6000, DMC8000

The above referenced equipment is **APPROVED** for seismic application when properly installed³, used as intended, and contains a Seismic Certification Label referencing this Certificate of Compliance⁴. As limited by the tabulated values, below grade, grade, and roof-level installations, installations in essential facilities, for life safety applications, and/or of equipment containing hazardous contents are permitted and included in this certification with an Equipment Importance Factor assigned as I_p =1.5. The equipment is qualified by successful seismic shake table testing at the nationally recognized Dynamic Certification Laboratories under the witness of the ISO Accredited Product Certification Agency, the VMC Group.

Certified Seismic Design Levels						
Certified IBC	Importance $I_p \le 1.5$	z/h ≤ 1.0	z/h = 0.0			
	Soil Classes A-E Risk Categories I-IV Design Categories A-F	S _{DS} ≤ 2.000 g	S _{DS} ≤ 2.500 g			
Certified EC8 ⁸	Importance Y _a ≤ 1.5 Soil Classes A-E, Type I-II	a _g ≤ 0.165 g	a _g ≤ 0.374 g			

Certified Seismic Installation Methods

Rigid Mounting From Unit Base To Rigid Structure

HEADQUARTERS

113 Main Street Bloomingdale, NJ 07403 Phone: 973.838.1780 Toll Free: 800.569.8423 Fax: 973.492.8430

102S-103387 Rev18

CALIFORNIA 180 Promenade Circle Suite 300 Sacramento, CA 95834 Phone: 916.634.7771

TEXAS

11930 Brittmoore Park Drive Houston, TX 77041 Phone: 713.466.0003 Fax: 713.466.1355 thevmcgroup.com







Certified Product Table:

Mode	I	Height	Depth	Widt	h	Weig	lht		
DMC 20	00	00	01	01		563	3		
DMC 60	00	90	31	31		71()		
DMC 80	00			 					
Туре	SD	_s (z/h=0)	S _{DS} (z/	′h=1)	A	Flex-H	A_{Rig-H}	A _{Flex-V}	A _{Rig-V}
AC156		2.5	2.0)	З	3.20	2.40	1.34	0.54

VMC GROUP

THE POWER OF TOGETHER™

This certification includes the Simpisync Digital Master Controller and included factory supplied options. This certification only covers options as shown in the chart above. The applicable options shall be installed per the manufacturer supplied seismic installation instructions. For a list of certified configurations and options please directly contact the manufacturer. This certification excludes all non-factory supplied accessories and options, including but not limited to isolation/restraint devices, other electrical/mechanical components and all connections for electrical or other pipe/conduit connections and configurations not detailed in the above charts. Flexibility in the connections must be maintained as to not transmit load into the equipment. Design specials are outside the scope of this certification.

 F_p/W_p

1.44



VMA-50122-01C (Revision 7) Issue Date: Thursday, October 1, 2015 Revision Date: Thursday, May 16, 2024 Expiration Date: Wednesday, June 30, 2027

102S-103387 Rev18





Cross-Code Compliance:

EC8 Approved Equivalent ag								
Earthquake Type	Install Height	f ₁ /f _a						
		0.01	0.10	0.50	1.0	2.0	100.0	
Type 2 Only	z/h = 0.0	0.701	0.614	0.374	0.284	0.711	0.711	
Type 1 Only		0.496	0.496	0.481	0.366	0.496	0.496	
Type 1 and Type 2				0.374	0.284			
Type 2 Only	z/h = 1.0	0.281	0.253	0.165	0.129	0.284	0.711	
Type 1 Only		0.361	0.325	0.213	0.166	0.366	0.496	
Type 1 and Type 2		0.281	0.253	0.165	0.129	0.284	0.490	

VMC GROUP

THE POWER OF TOGETHER"

* The type of earthquake to use per country/region is listed in the national annex

* The f_1/f_a is fundamental frequency of the building divided by that of the component

 \ast The column for f_1/f_a can be used as the most conservative approved ground motion



VMA-50122-01C (Revision 7) Issue Date: Thursday, October 1, 2015 Revision Date: Thursday, May 16, 2024 Expiration Date: Wednesday, June 30, 2027

102S-103387 Rev18





Notes & Comments:

- 1. All equipment listed herein successfully passed the seismic acceptance criteria for shake testing non-structural components and systems as set forth in the ICC AC-156. The Test Response Spectrum (TRS) enveloped the Required Response Spectrum (RRS) for all units tested. The tested units were representative sample(s) of a contingent of models and all remained captive and structurally sound after the seismic shake simulation. The units also remained functionally operational after the simulation testing as functional testing was completed by the equipment manufacturer before and after the seismic simulations. Although a seismic qualified unit inherently contains some wind resisting capacity, that capacity is undetermined and is excluded from this certification. Snow/Ice loads have been neglected and thus limit the unit to be installed both indoors (covered by an independent protective structure) and out of doors (exposed to accumulating snow/ice) for ground snow loads no greater than 30 psf for all applications.
- 2. The following building codes are addressed under this certification:
 - IBC 2021 referencing ASCE7-16 and ICC-ES AC-156 IBC 2018 referencing ASCE7-16 and ICC-ES AC-156 IBC 2015 referencing ASCE7-10 and ICC-ES AC-156 IBC 2012 referencing ASCE7-10 and ICC-ES AC-156 EC8 2004 full reference Eurocode EN-1998 2004
- Italian Eurocode 8 Annex Published 2012 (Building Code Annex) 3. Refer to the manufacturer supplied installation drawings for anchor requirements and mounting

VMC GROUP

THE POWER OF TOGETHER"

- 3. Refer to the manufacturer supplied installation drawings for anchor requirements and mounting considerations for seismic applications. Required anchor locations, size, style, and load capacities (tension and shear) may be specified on the installation drawings or specified by a 3rd party. Mounting requirement details such as anchor brand, type, embedment depth, edge spacing, anchor-to-anchor spacing, concrete strength, special inspection, wall design, and attachment to non-building structures must be outlined and approved by the Engineer of Record for the project or building. Structural walls, structural floors, and housekeeping pads must also be seismically designed and approved by the project or building Structural Engineer of Record to withstand the seismic anchor loads as defined on the installation drawings. The installing contractor is responsible for ensuring the proper installation of all anchors and mounting hardware.
- 4. For this certificate and certification to remain valid, this certificate must correspond to the "Seismic Certification Label" found affixed to the unit by the factory. The label ensures the manufacturer built the unit in conformance to the IBC seismic design criteria set forth by the Certified Seismic Qualification Agency, the VMC Group, and meets the seismic design levels claimed by this certificate.
- 5. Mechanical, Electrical, and Plumbing connections to the equipment must be flexibly attached as to not transfer load through the connection. The structural integrity of any conduit, cable trays, piping, ductwork and/or flexible connections is the responsibility of others. This certification makes no statements of compliance in regards to NEMA, IP, UL, CSA, or other relevant standards after a seismic event. For compliance to other relevant standards, please contact the manufacturer.
- 6. This certificate applies to units manufactured at: 1400 73rd Avenue NE, Minneapolis, MN, 55432
- 7. This certification follows the VMC Group's ISO-17065 Scheme.
- 8. The Eurocode 8 maximum ground motion for equipment installed at grade or roof listed assumes that the fundamental frequency of the component is exactly twice that of the building (approximately 5 times more stiff compared to the building). If the frequency of the building or equipment is not known for a particular project, the cross-code table for EC8 may be used after the certified product table for the value of f_1/f_a as it represents the worst case amplification (and thus approves the lowest most conservative maximum ground motion).

John P. Giuliano, PE President, VMC Group



VMA-50122-01C (Revision 7) Issue Date: Thursday, October 1, 2015 Revision Date: Thursday, May 16, 2024 Expiration Date: Wednesday, June 30, 2027



102S-103387 Rev18